

## **Comdial Impact - Setting The System Clock**

You can program the system clock to maintain current date and time information. The time and date appear on the LCD speakerphone for display.

### **· To set the system clock from the attendant's station (Station 10):**

1. Press **INTERCOM**.
2. Dial **S # 0 1**.
3. Dial two digits (**00-99**) for year.
4. Dial two digits (**01-12**) for month.
5. Dial two digits (**01-31**) for day.
6. Dial two digits (**00-23**) for hour.
7. Dial two digits (**00-59**) for minutes.
8. Press **SPEAKER** to end.