


Norstar Meridian – Time and Date Set

1. Press **FEATURE** **8463 (which spells out TIME)
2. Enter Password 23646 (which spells out ADMIN)
3. Screen says “*Hour:___.*” Press CHANGE if you want to change it.
4. Press **NEXT**.
5. Screen says “*Minutes:_____*” Press CHANGE if you want to change it.
6. Press **NEXT**.
7. You can then scroll through the Month, Day and Year by pressing **NEXT**.
8. Press Rls or  when finished.